

Installation instructions for Parador laminate flooring Trendtime 3



Note: The installation instructions shown here deal exclusively with individual, important special features of the herringbone installation. Complete installation instructions can be found online in the laminate flooring guide: parador.de/guide-installation-download



Key steps:

When selecting the underlay, please ensure that it has sufficient compressive strength. This should not be less than 120 kPA. Softer, less compression-resistant underlays have a negative effect on installation stability.

Our Akustik Protect 80, Akustik Protect 100 and Akustik Protect 500 products meet this requirement.

Please note that the planks must be installed so that the groove side of the planks is in the direction of installation and that the tongue is clicked into the groove.

Please ensure that all planks are correctly locked. Planks are correctly locked when accompanied by an acoustic clicking sound. In addition to a vertical tap to lock the head end into the long side, we also recommend a horizontal tap in every three rows to finally lock the planks in place.

Please glue together the planks of the first and last full three rows. If the floor is laid on underfloor heating or the relative humidity is not between 30 % - 65 %, glue all the planks together.

To do this, please apply Parador D3 glue sparingly to the glue areas of the long and end edges. Avoid excessive amounts to prevent glue from leaking into the V-joint.

The planks must be clicked together completely tight. For this purpose, the planks can be pulled together completely tight, for example, with a tape (adhesive tape).

For fixing in place, please weigh down the glued areas evenly and across the planks.

Make sure that the glue has cured.

Custom-cut planks must be inserted into the rectangular free spaces.

Please glue these cut or shortened planks together.

To do this, proceed in the same way as for the first and last three full rows:

1. Apply D3 glue sparingly on the long and end edges;
2. Make sure that planks are installed tightly;
3. Weigh down evenly, across the planks
4. Allow glue to cure

Alternatively, if you want to glue the flooring over the whole area, please contact us in advance.

The complete step-by-step installation instructions can be found in detail online at: parador.de/guide-installation-download

